
MB2152 - Installation Instructions JL Front Seat Mount

JL/JLU FRONT SEAT MOUNT


2018-CURRENT




INSTALLATION INSTRUCTIONS

MB2152 - Shipping JL/JLU Front Seat Mounts


CONTENTS




MB2152-01
Qty: 2




MB2152-01_MIR
Qty: 2




MB2152-04
Qty: 4




MB2152-05
Qty: 2




MB2152-02
Qty: 1




MB2152-02_MIR
Qty: 1




3/8"-16 x 1" Hex Bolt
Qty: 16




3/8" Flat Washer
Qty: 32




MB2152-03
Qty: 1



MB2152-03_MIR
Qty: 1




3/8"-16 Nylon Locking Nut
Qty: 16





5/16" Flat Washer
Qty: 8

SEAT SLIDER KIT
Qty: 2




SEAT SLIDER
Qty: 1






5/16"-18 x 3/4" Carriage Bolt
Qty: 4




5/16"-18 Nylon Insert Hex Locknut
Qty: 4




5/16" Flat Washer
Qty: 8


MB2152 - Installation Instructions JL Front Seat Mount

SEAT MOUNTING DIMENSIONS






SIDE




BOTTOM


MB2152 - Installation Instructions JL Front Seat Mount




MB2152 - Installation Instructions JL Front Seat Mount




MB2152 - Installation Instructions JL Front Seat Mount







MB2152 - Installation Instructions JL Front Seat Mount




MB2152 - Installation Instructions JL Front Seat Mount






REPEAT ON OPPOSITE SIDE


MB2152 - Installation Instructions JL Front Seat Mount



MB2152 - Installation Instructions JL Front Seat Mount

MB2152-04





OPTIONAL SEAT RISER

SEAT CAN BE MOUNTED TO MB2152-01 OR M2152-04
DEPENDING ON THE HEIGHT OF THE DRIVER.