



MB2205**MB2205 - Electronics & ABS Relocation Kit**

Compatible with Year Model (07-18 JK/JKU)


**ASSEMBLY INSTRUCTIONS**

MB2205


CONTENTS




MB2205-01
Qty 1




MB2205-03
Qty 1




MB2205-02
Qty 1




MB2205-04
Qty 1




MB2205-05
Qty 1




MB2205-07
Qty 1




MB2205-06
Qty 1




MB2205-08
Qty 1




#10-24 x 1/2" BHS-SS
Qty 10



1/4-20 x 3/4" BHS-SS
Qty 6



M6 x 1 x 10 Hex Head
Qty 2



#10-24 x 1.75 Phillips Screw
Qty 3



Preparation and Installation Guide

Compatibility: This relocation kit is designed to be used with the MB3103 JK/JKU front half kit or if you have shock towers that require you to remove the factory plastic trays.

1. Instructions Disclaimer: These instructions do not show the removal or disconnection of the factory plastic trays or electronics.


2. ABS Brake lines: There is no need to remove the brake lines going in to the ABS unit. there is enough play to allow the unit to move.

3. Wiring: After installing the new bracket check that there is clearance and the wiring for the ECU and the fuse box is secured and away from any moving parts or shock springs.

Pro Tip: Use STEEL-IT paint, which can be welded through and easily touched up afterward.


MB2205

ASSEMBLE THE BATTERY/FUSE BOX TRAY AS WELL AS SECURE THE TCM TO ITS NEW RELOCATION BRACKET.




MB2205

SECURE THE BATTERY/FUSE BOX TRAY USING THE 3 STUDS ON THE FIRE WALL




MB2205

USING THE FACTORY FENDER FASTENERS SECURE ALL THE RELOCATION BRACKETS THE FENDER SUPPORT. THE BRACKETS WILL LOCATE USING THE FACTORY THREADED HOLES.




MB2205

SECURE THE ABS UNIT TO MB2205-01 BRACKET USING THE PROVIDED FASTNERS. YOU WILL NEED TO REMOVE THE FACTORY BOLTS FROM ABS UNIT BEFORE PUTTING ON THE BRACKET.





MB2205



MB2205

**PLACE THE FUSE BOX IN THE BATTERY BOX/FUSE BOX ASSEMBLY.
THE FUSE BOX SHOULD CLICK IN TO PLACE. ADJUST THE MB2205-05 IF NEEDED.
RECONNECT THE WIRING AFTER SECURED.**



MB2205

LEGAL DISCLAIMER

Motobilt, Inc. products are designed and manufactured primarily for **OFF-ROAD USE ONLY**. They are not certified or approved for street or highway use and may not comply with vehicle safety standards or regulations. Vehicle modifications, including the installation of Motobilt, Inc. products, may alter the handling, performance, and durability of a vehicle.

By purchasing, installing, or using any Motobilt, Inc. product, the purchaser and installer expressly acknowledge and agree to the following terms:

1. ASSUMPTION OF RISK

The purchaser and installer understand and accept that the installation and use of aftermarket products involve inherent risks, including but not limited to vehicle damage, property damage, serious injury, or death. All such risks are voluntarily assumed.

2. NO WARRANTY OF SAFETY

Motobilt, Inc. makes no representations, warranties, or guarantees, express or implied, regarding the safety, performance, or structural integrity of its products. Motobilt, Inc. products are not intended to prevent injury or death in the event of an accident, rollover, or collision.

3. INSTALLATION RESPONSIBILITY

Some Motobilt products require advanced fabrication, cutting, or welding skills. Others may require specialized tools or mechanical knowledge. Motobilt, Inc. is not responsible for improper installation, modification, or misuse of its products. Professional installation by a qualified individual is strongly recommended.

4. COMPLIANCE WITH LAWS AND REGULATIONS

The purchaser and installer are solely responsible for ensuring that the vehicle and installed products comply with all applicable local, state, and federal laws and safety regulations. Vehicle modifications may void factory warranties and may render the vehicle illegal for use on public roads.

5. MAINTENANCE AND INSPECTION

All products should be inspected regularly for signs of wear, fatigue, or damage. Continued use of damaged or improperly installed equipment increases the risk of failure and potential injury. The responsibility for inspection and maintenance rests solely with the owner and operator.

6. WARRANTY DISCLAIMER

Unless expressly stated in a written limited warranty issued by Motobilt, Inc. for a specific product, all Motobilt, Inc. products are sold "as is" and without express warranties of any kind. If a written limited warranty applies, its terms are exclusive and govern the extent of Motobilt, Inc. obligations.

To the fullest extent permitted by law, Motobilt, Inc. expressly disclaims all implied warranties, including but not limited to implied warranties of merchantability, fitness for a particular purpose, and non-infringement. No oral or written statement by Motobilt, Inc., its employees, dealers, or representatives shall constitute or create any warranty, obligation, or liability beyond what is contained in official written documentation issued by Motobilt, Inc.

7. LIMITATION OF LIABILITY

To the fullest extent permitted by law, Motobilt, Inc. disclaims all liability for any direct, indirect, incidental, consequential, or punitive damages arising out of the purchase, installation, or use of its products. This includes, but is not limited to, claims for property damage, personal injury, loss of use, or loss of income.

8. USER ACKNOWLEDGMENT

By purchasing, installing, or using Motobilt, Inc. products, the purchaser and installer acknowledge that they have read, understood, and accepted the terms of this disclaimer and voluntarily assume all associated risks.